CKG2-RM Quick Start Guide Package Contents UCK G2 Rackmount Accessory **System Requirements** • UniFi Cloud Key G2 or Cloud Key G2 Plus Standard 19" Server Rack **Hardware Overview Front Panel Note:** This section provides an overview of the front panel as it would function with a Cloud Key installed in the Docking Bay. 1 LED White Ready for configuration Flashing White Initializing Firmware upgrade in progress. Device is busy; do not Heartbeat Flashing White touch or unplug it. Device ready for use Blue Shutting down Flashing Blue Rapid Flashing Blue Device failure; refer to the display for more information. User connected to device Slow Flashing Blue Repeating Off/White/Blue Recovery mode 2 Ethernet Port Connects to a DHCP server on your LAN. Power can be provided by an 802.3af PoE switch, such as the UniFi PoE Switch. 3 Reset Button The Reset button serves two functions: • Restart Press and release the Reset button quickly to restart the Cloud Key. Restore to Factory Default Settings Press and hold the Reset button for more than five seconds to restore factory default settings to the Cloud Key. **Back Panel** 4 Lock Tab Mechanism that allows you to adjust the size of the Docking Bay depending on which Cloud Key you are using: UCK-G2 or UCK-G2-PLUS. 5 Docking Bay Interface where the Cloud Key connects to the rackmount. Hardware Installation OR Connecting the Cloud Key G2 2. Warning: To prevent creating a loop or other unfavorable behavior on the network, only one Ethernet connection should be used. Do not use the Ethernet ports on the Cloud Key G2 and Rackmount Accessory simultaneously. Connecting the Cloud Key G2 Plus 2. 3.



27.10 x 46.80 x 119.75 mm Dimensions (1.07 x 1.84 x 4.71") 172 g (6.07 oz) Weight

Enclosure	Aluminun
Management Interface	UniF
Networking Interface	(1) 10/100/1000 Ethernet Por
Buttons	(1) Reset to Defaults Powe
Power Method	802.3af Pol DC 5V, 1A
Power Supply	802.3af PoE o USB-C 5V, Minimum 1 <i>A</i>
Max. Power Consumption	5V
Operating Temperature	0 to 35° ( (32 to 104° F
Operating Humidity	20 to 80% Noncondensing
Certifications	CE, FCC, IC

## 2. Heed all warnings. 3. Only use attachments/accessories specified by the manufacturer. **WARNING:** Do not use this product in location that can be submerged by water.

**Safety Notices** 

**WARNING:** Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

1. Read, follow, and keep these instructions.

**Electrical Safety Information** 1. Compliance is required with respect to voltage, frequency, and current requirements indicated on

where applicable, specify arbitration instead of jury trials or class actions.

the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed. 2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.

## **Limited Warranty** ui.com/support/warranty The limited warranty requires the use of arbitration to resolve disputes on an individual basis, and,

Compliance **Battery Warning** 

1. Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.

2. Do not use any cell or battery which is not designed for use with the equipment. 3. Always purchase the battery recommended by the device manufacturer for the equipment. 4. Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or equipment manual for proper charging instructions.

Australia and New Zealand

applicable to it.

Warning: This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference. **CE Marking** CE marking on this product represents the product is in compliance with all directives that are





**Declaration of Conformity** 





